


FMEU FRONT PANEL CONTROLS



Clean with a soft dry cloth

Do not allow water or liquids to splash or drip on to the unit.



MANUFACTURED BY:-



BRUNEL DRIVE
STRETTON BUSINESS PARK
BURTON UPON TRENT
STAFFORDSHIRE
ENGLAND
DE13 0BZ


TEL +44 1283 500 500
FAX +44 1283 500 400
WEB: www.gai-tronics.co.uk

Doc No. 502-20-0094-008

iss2 CN 20713

FMEU
FM Entertainment unit
Receiver

Operating Instructions




FMEU Radio Function

- To turn ON the radio. Momentarily Press the ON/OFF button. The time display is then replaced with the current tuned Frequency.
- To adjust the volume of the Loudspeaker / Headphones press the volume UP or DOWN buttons. Warning: excessive volume may damage hearing – please ensure sound level is not too high, especially in headphones.
- To change the frequency, press the TUNE UP or TUNE DOWN button.
- Pressing the Tune UP or DOWN briefly, changes the frequency by 50KHz.
- Press and hold the TUNE UP or DOWN button for more than 1 second to use Auto Scan Tuning. When the first station is found the tuning will stop.
- To turn off the radio momentarily press the ON/OFF button. The current time will replace the frequency in the display.

Storing / Recalling your Favourites

- To store your favourite channels. Tune to the required frequency, Momentarily press the 'MEM STORE' button, where a 'M' will appear above the frequency. To store in locations 1 – 5, press the desired location then press the 'MEM STORE' button again.
- To store the frequency in locations 6 – 10. Press the 'MEM STORE' button then the '+5' button then the required memory location 1 – 5 (6 – 10), then the 'MEM STORE' button again.
- The memory location is now displayed in the top right hand corner of the display.
- To recall your favourite frequencies, press the location buttons 1 – 5, and for locations 6 – 10 press the '+5' button then locations 1 – 5.



Setting the Current Time

- While the radio is OFF, press and hold the 'SET MODE' button until the time begins to flash. While the time is flashing press the TUNE UP button to increment the Minuets and the TUNE DOWN button to increment the Hours. Press the 'SET MODE' button again to store the current time.
- To set the current time while the radio is on, press the 'SET MODE' button once to display the time, then press and hold the 'SET MODE' button until the time begins to flash, press the TUNE UP button to increment the Minuets and the TUNE DOWN button to increment the Hours. Press the 'SET MODE' button again to store the current time.
- To set the Alarm Wake up time while the radio is on, press the 'SET MODE' twice. The STANDBY symbol will be flashing at the bottom of the display. Press and hold the 'SET MODE' button. The alarm time will now flash. While the alarm time is flashing press the TUNE UP button to increment the Minuets and the TUNE DOWN button to increment the Hours. Press the 'SET MODE' button again to store the alarm time.

Wake up ALARM setting

- To set a wake up call
- Set the Alarm time as describe previously
- Press the 'ALARM ON/OFF' at any time.
- The symbol STANDBY will appear at the bottom of the display to indicate that the Alarm is set.
- When the alarm time is reached, an audible alarm is heard and the symbol will be flashing next to the STANDBY symbol.
- To silence and cancel the alarm, press the 'ALARM ON/OFF' or to silence only, press the ON/OFF button.
- If the radio is switched on during the Alarm signal pressing the ON/OFF button will silence the alarm.

